

#### ASSEMBLY INSTRUCTIONS

#### **ROMA PERGOLA**

(68543009)

#### ATTENTION:.

- 1. Please read these instructions carefully before assembly
- 2. Aluminium is soft metal and over tightening may strip thread or break the part
- 3. <u>DO NOT</u> use power tools you will need a Philips screwdriver to assemble the pergola
- 4. Please allow 60 minutes for assembly
- 5. Assembly will require 2 people and the use of a tall step ladder

# **ASSEMBLY STEPS:**

- 1. Lay out beams (A, B,C, C1, D& Y) and attach beams(C1&D,C&D) together using screws(Z), decorative end (G) to each end of beams using mallet (T) to gently tap them in
- 2. Push legs (E) into base plate (H) and using a Philips screwdriver attach the bolts and washer (K)
- 3. Push beams (C1&D,C&D) into top of legs (E) using mallet (T) to gently tap them in
- 4. Hold leg sections up and attach beams (B) to either end of pergola using mallet (T) to gently tap them in
- 5. Attach end caps (M) to top of legs (E)
- 6. Attach beam (A) to centre of pergola and beam(Y) on the two sides of (A)using mallet (T) to gently tap them in
- 7. Hook double rings (I) to hook on beam (A& C,D)
- 8. Attach canopy (Q) to single and double rings across pergola frame
- 9. Insert canopy supports (F,N) through and into canopy (Q) attach canopy end supports to canopy supports (N)
- 10. Thread cord (O) through runners on beams (C & C1). Follow image below.
- 11. Attach bracket (V) to leg (E) with bolts (S) same side as beam (C1&D)
- 12. Fit canopy cover (U) to top of pergola nearest to beam (C1) so it covers the canopy when closed
- 13. Attach legs (E) to floor using bolts (L) or nails (P) if attaching to grass
- 14. Canopy holder (R) can be attached when required to hold canopy in place

For more information regarding maintenance of your furniture please visit <a href="http://www.hartmanuk.co.uk/after\_care\_videos.html">http://www.hartmanuk.co.uk/after\_care\_videos.html</a>


For replacement or lost spare parts please go to <a href="http://faq.hartmanuk.co.uk/spares/">http://faq.hartmanuk.co.uk/spares/</a>


Parts List	Parts Picture	Description	Qty	Part No
А	80000	Beam	1	68543009A
В	00000	Beam	2	68543009B
Y		Beam	4	68543009Y
С		Beam	1	68543009C
C1		Beam	1	68543009C1
D		Beam	2	68543009D
E		Leg	4	68543009E
N	( <u> </u>	Canopy Support Ends	6	68543009N
F		Canopy Supports	6	68543009F


Parts List	Parts Picture	Description	Qty	Part No
G		Decorative beam End	18	1401163
Н		Base Plate	4	1411163
I		Double Ring runner	2	1411165
J		Single Ring runner	16	1411166
К	M6 × 12	Bolt & Washer	8	1411167
L	M8 × 80	Fixing Bolt	16	1411168
М		End Cap	16	1411169
0		Cord	1	1411171
Р		Peg	4	1411183

For replacement or lost spare parts please go to <a href="http://faq.hartmanuk.co.uk/spares/">http://faq.hartmanuk.co.uk/spares/</a>

Q		Canopy	1	68543009Q
R		Canopy Holder	1	68543009R
S	M4 × 32	Bolt	2	1561182
Т		Mallte	1	1411175
U	The same of the sa	Canopy Cover	1	68543009U
V		Bracket	1	1411178
W		Touch Up Pen	1	1411177
х		Toggle Tie	8	1411179
Z	₩4 × 19	Bolt	6	1600001













For replacement or lost spare parts please go to <a href="http://faq.hartmanuk.co.uk/spares/">http://faq.hartmanuk.co.uk/spares/</a>














For replacement or lost spare parts please go to <a href="http://faq.hartmanuk.co.uk/spares/">http://faq.hartmanuk.co.uk/spares/</a>

